LASVIT EVE MANUAL UL

Eve Collection by Zaha Hadid




Contents

Technical parameters	1	
Step-by-step installation	2	
Fixing point preparation	3	
Fixing	3	
Suspension cable	6	
Electrical wiring	7	
Canopy mounting	10	
Installation of the glass components	11	
Installation of the glass components	25	
Installation of the lamp cover	26	
Light source replacement	27	
Installation notes	27	
Warranties and Warranty Terms and Conditions		

Markings



Warns you of high risk of damage to the fixture or injury.



Warns you of high risk of electrical injury should a live part be directly or indirectly touched.

! Notice

Warns you about possible damage to the fixture.

i Important

Important information regarding the usage of your fixture.

■ Note

Gives you general information about the usage of your fixture.

Please read this manual carefully and keep it in case you need assistance while performing maintenance and cleaning procedures.

LASVIT GLASS COLLECTIONS ARE UNIQUE AND HANDCRAFTED.

Tiny bubbles and other irregularities may occur due to the nature of the glass-blowing technique.

Thank you for purchasing a Lasvit Collection.

1/ Technical parameters

Item ID / CLo37PA-1UL

Dimensions / Ø 530 mm x H 720 mm + L

Color variants / clear

Weight / approx. 45 kg

Input voltage / 220 - 240 V AC, 50 Hz

Rated power / max. 144 W

Light source / 11× LED module

Protection rating / IP 20

Safety class / CLASS I

Please read this manual carefully and keep it in case you need assistance while performing maintenance and cleaning procedures.

1

2/ Step-by-step installation


negligent or accidental switching on.

Before starting any procedures make sure that the power to the lighting fixture is switched OFF and secured against unauthorized,

Should the cable need to be shortened, ask a qualified technician (licensed electrician) to disconnect the cable, shorten it and reconnect it, detail instructions can be found in the chapter **Cable shortening**. The same

applies to lenghtening the cable, however a new, longer cable needs to be purchased separately. Lasvit shall not be held liable for any injuries or damage to the fixture or other property caused by unauthorised manipulation with the cable or its parts.
To retain quality of hand-blown glass, Lasvit recommends to clear the glass at least every 3 months.
Fixing material is not part of the lighting fixture kit. Refer to the relevant section of this manual for suitable fixing materials and components.
Proper fixing shall be the responsibility of the customer.
⚠ Installation and electrical wiring should be carried out by a qualified electrician to prevent any damage to health or property.
The manufacturer shall not be held liable for any defects caused by unqualified handling of the lighting fixture.
This lighting fixture is to be mounted on fire proof surfaces.
⚠ Do not cover the lighting fixture with any material, it is necessary for the hot parts to be cooled by freely flowing air, otherwise there is a risk of fire.
Do not spin the pendant! Spinning the pendant may result in breaking of the suspension cable and/or electrical malfunction!
For indoor use only. Installation requires 2–3 persons.

3/ Fixing point preparation



4/ Fixing

Fixing material is not included.


Lasvit shall not be held liable for any injuries or damage to the fixture or other property caused during installation or by improper fixing.

Consulting a specialist before choosing type of fixing materials and procedures for a given fixture is highly recommended.

Pictures shown are for illustration purposes only.


4.1/ Threaded rods

First prepare a 4" J-Box and PE cable, then you may proceed with the mount installation.



4.2/ Bolts/screws


First prepare a 4" J-Box and PE cable, then you may proceed with the mount installation.




5/ Suspension cable

Take care not to break the grounding (pos. A).

It's necessary to have minimal 50 mm overlap of the wire (pos B) above the wire holder (pos C). This is of the safety reasons.




6/ Electrical wiring



6.1/ Light source cable


Detail 1




6.2/ Connection of mains input and light source output


Detail 2

⚠ Driver TR1, TR2 dimming has to be connected separately!






Detail 3



7/ Canopy mounting


Take care not to break the grounding (pos. A).





8/ Installation of the glass components

Please be careful during the glass installation and do not damage the glass parts. Damage to glasses by improper handling will void your free replacement.


8.1/ Preview and positioning of the glass components









8.2/ Installation of the glass components (Part 1)




8.3/ Glass component positioning







Detail 4




Detail 5



Detail 6




After aligning the glass component to the ideal position, lock the component with the nut (pos. E).




8.4/ Installation of the glass components (Part 2)


Step 1



Step 2




Step 3




8.5/ Connection of light source output

Step 4




In the picture you can see the connection of all the glass components which you will connect consecutively.

Step 5




8.6/ Installation of the lamp cover




9/ Installation of the glass components

Please install the remaining glass components according to the same procedure in Chapter 8. Be careful to follow the correct glass rotation procedure, see picture (step 6). The procedure is described only for one type of glass (glass 2), which can be applied for all the installations.

Step 6



10/ Installation of the lamp cover



11/ Light source replacement

In case of light source failure, please contact the Lasvit manufacturer.

12/ Installation notes

12.1/ Cable shortening

This adjustment can be carried out only by a qualified electrician (trained electrician).


igwedge Perform the cable adjustment according to valid standards.

Picture 1: Adjusted cable from the manufacturer (LASVIT).

Picture 2: Shortening the cable to the desired length.

Picture 3: Remove only the top insulation. The basic insulation of the conductor must not be broken.

Picture 4: Final adjustment of the cable for its connection. Additional insulation (positions F, G, H, I), stripped ends of wires with tubes.



13/ Warranties and Warranty Terms and Conditions

1/ The warranty is defined in the Price Quotation, Price Agreement, Contract, or Order. If the Price Quote, contract, or order is not issued, the warranty does not apply to resources, maintenance, service and cleaning and the standard warranty on the goods is set for 2 years. Other agreed warranties must be specified in the Price Quotation, Price Agreement, Contract, or Order.

2/ As a basis for the claim, the customer must provide a valid contract, invoice, or other proof of payment. Otherwise, the manufacturer reserves the right to refuse to provide a warranty, so keep the proof of product purchase carefully.

3/ If the warranty applies to the defect found, the customer informs the seller by e-mail, telephone, or the Sales department of the manufacturer (Lasvit) and passes the required information (project number or light number, project or light name and describes the defect).

4/ The Sales Department proceeds on the basis of an internal customer complaint resolution directive.

5/ The manufacturer will analyse the occurrence of a disagreement with the customer or with the manufacturer after delivery of the non-conforming product to the manufacturer's premises.

6/ Once the analysis has been made, the Sales department is handed over the decision to accept or reject the complaint with an explanation.

7/ The Sales department agrees with the customer for further steps (e.g. repair or replacement date, etc. on the basis of customer and manufacturer possibilities). Unless otherwise agreed, the manufacturer is obliged to remove the defect within 30 days of the claim date at the manufacturer's expense.

8/ The warranty does not apply to:

- defects caused by the customer
- defects caused by a third party
- defects caused by regular usage
- defects caused by an installation contrary to the installation manual
- defects caused by inappropriate attachment or product connection
- defects caused by performed in contradiction with the cleaning manual

- defects caused by the use of other than defined light sources
- defects caused by installation in premises that do not correspond to the nature of the light and its IP cover (intrusion protection).
- defects caused by force majeure
- 9/ The company LASVIT has the exclusive right to grant, deny or change the terms and conditions for the provision of warranty services.



Never dispose of this product in mixed municipal waste, it must be submitted at the designated disposal installation.

The fxture was designed and manufactured by / Lasvit s.r.o. / Komunardů 32 / 170 00 Praha 7 / Czech Republic T +420 481 120 810 / F +420 481 120 622 / E lasvit@lasvit.com lasvit.com

Manual created

27.06.2019

In case you need any assistance or have any suggestion, please contact us at

lasvit.com